

# Mamac Systems Industrial Parts Catalog

## Axiparts Global Industrial RFQ Platform

Email: [info@axiparts.com](mailto:info@axiparts.com)

Website: <https://axiparts.com>

Premium RFQ catalog for Mamac Systems industrial spare parts, MRO components and replacement products. Every listed product is linked directly to its live RFQ product page.

**Brand:** Mamac Systems

**Listed Products in This PDF:** 123

**Catalog URL:** <https://axiparts.com/catalogs/brands/mamac-systems.pdf>

Part Number	Product Description	Live RFQ Link
cod.TE-703-B-12-B	cod.TE-703-B-12-B Temperature sensor	<a href="#">Open Product RFQ Page</a>
HU-224	HU-224 3% CHANNEL TYPE HUMIDITY SENSOR	<a href="#">Open Product RFQ Page</a>
HU-224-2-mA	HU-224-2-mA Relative Humidity Transducer	<a href="#">Open Product RFQ Page</a>
HU-224-2-VDC	HU-224-2-VDC	<a href="#">Open Product RFQ Page</a>
HU-224-3-	HU-224-3- VDC	<a href="#">Open Product RFQ Page</a>
HU-225	HU-225	<a href="#">Open Product RFQ Page</a>
HU-225-2-MA	HU-225-2-MA HUMIDITY SENSOR	<a href="#">Open Product RFQ Page</a>
HU-225-2-VDC	HU-225-2-VDC Humidity Sensor	<a href="#">Open Product RFQ Page</a>
HU-225-3-VDC	HU-225-3-VDC Humidity Sensor	<a href="#">Open Product RFQ Page</a>
HU-226-3VDC-17	HU-226-3VDC-17 Original Spare Part	<a href="#">Open Product RFQ Page</a>
PR-274	PR-274 Low Pressure Transducer	<a href="#">Open Product RFQ Page</a>
PR-274-R3-MA	PR-274-R3-MA Low Pressure Sensor	<a href="#">Open Product RFQ Page</a>
PR-274-R6-MA	PR-274-R6-MA Low Pressure Sensor	<a href="#">Open Product RFQ Page</a>
PR-275	PR-275 Low Pressure Transducer	<a href="#">Open Product RFQ Page</a>
PR-276-R13-MA	PR-276-R13-MA	<a href="#">Open Product RFQ Page</a>
PR-282-3-3-B-1-2-B	PR-282-3-3-B-1-2-B Sensor	<a href="#">Open Product RFQ Page</a>
PR-282-3-4-B-1-2-B	PR-282-3-4-B-1-2-B	<a href="#">Open Product RFQ Page</a>
PS-200-1-A-3-L	PS-200-1-A-3-L -	<a href="#">Open Product RFQ Page</a>
TE-205-EU-12	TE-205-EU-12 Space Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-211.	TE-211.	<a href="#">Open Product RFQ Page</a>
TE-211Z-A-1-E-7	TE-211Z-A-1-E-7 Temperature Transducer	<a href="#">Open Product RFQ Page</a>
TE-213-A-1-C-7	TE-213-A-1-C-7 Space Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-213-B-B-2-1-C-7	TE-213-B-B-2-1-C-7 Original Spare Part	<a href="#">Open Product RFQ Page</a>
TE-213-B-D-2-2-C-7	TE-213-B-D-2-2-C-7	<a href="#">Open Product RFQ Page</a>
TE-701-A-10-A	TE-701-A-10-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>

Part Number	Product Description	Live RFQ Link
TE-701-A-12-A	TE-701-A-12-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-13-A	TE-701-A-13-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-14-A	TE-701-A-14-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-15-A	TE-701-A-15-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-16-A	TE-701-A-16-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-17-A	TE-701-A-17-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-18-A	TE-701-A-18-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-1-A	TE-701-A-1-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-1-B	TE-701-A-1-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-21-A	TE-701-A-21-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-2-A	TE-701-A-2-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-2-B	TE-701-A-2-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-3-A	TE-701-A-3-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-3-B	TE-701-A-3-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-4-A	TE-701-A-4-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-4-B	TE-701-A-4-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-5-A	TE-701-A-5-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-5-B	TE-701-A-5-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-7-A	TE-701-A-7-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-7-B	TE-701-A-7-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-8-A	TE-701-A-8-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-A-8-B	TE-701-A-8-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-10-A	TE-701-B-10-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-12-A	TE-701-B-12-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-13-A	TE-701-B-13-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-14-A	TE-701-B-14-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-15-A	TE-701-B-15-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-16-A	TE-701-B-16-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-17-A	TE-701-B-17-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-18-A	TE-701-B-18-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-1-A	TE-701-B-1-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-1-B	TE-701-B-1-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-21-A	TE-701-B-21-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-2-A	TE-701-B-2-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>

Part Number	Product Description	Live RFQ Link
TE-701-B-2-B	TE-701-B-2-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-3-A	TE-701-B-3-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-3-B	TE-701-B-3-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-4-A	TE-701-B-4-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-4-B	TE-701-B-4-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-5-A	TE-701-B-5-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-5-B	TE-701-B-5-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-7-A	TE-701-B-7-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-7-B	TE-701-B-7-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-8-A	TE-701-B-8-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-B-8-B	TE-701-B-8-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-10-A	TE-701-C-10-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-12-A	TE-701-C-12-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-13-A	TE-701-C-13-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-14-A	TE-701-C-14-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-15-A	TE-701-C-15-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-16-A	TE-701-C-16-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-17-A	TE-701-C-17-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-18-A	TE-701-C-18-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-1-A	TE-701-C-1-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-1-B	TE-701-C-1-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-21-A	TE-701-C-21-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-2-A	TE-701-C-2-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-2-B	TE-701-C-2-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-3-A	TE-701-C-3-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-3-B	TE-701-C-3-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-4-A	TE-701-C-4-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-4-B	TE-701-C-4-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-5-A	TE-701-C-5-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-5-B	TE-701-C-5-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-7-A	TE-701-C-7-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-7-B	TE-701-C-7-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-C-8-A	TE-701-C-8-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-10-A	TE-701-D-10-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>

Part Number	Product Description	Live RFQ Link
TE-701-D-12-A	TE-701-D-12-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-13-A	TE-701-D-13-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-14-A	TE-701-D-14-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-15-A	TE-701-D-15-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-16-A	TE-701-D-16-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-17-A	TE-701-D-17-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-18-A	TE-701-D-18-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-1-A	TE-701-D-1-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-1-B	TE-701-D-1-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-21-A	TE-701-D-21-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-2-A	TE-701-D-2-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-2-B	TE-701-D-2-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-3-A	TE-701-D-3-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-3-B	TE-701-D-3-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-4-A	TE-701-D-4-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-4-B	TE-701-D-4-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-5-A	TE-701-D-5-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-5-B	TE-701-D-5-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-7-A	TE-701-D-7-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-7-B	TE-701-D-7-B Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-701-D-8-A	TE-701-D-8-A Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-702-A-12-D	TE-702-A-12-D Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-702-A-17-D	TE-702-A-17-D Duct Temperature Sensor	<a href="#">Open Product RFQ Page</a>
TE-703-B-12-A	TE-703-B-12-A	<a href="#">Open Product RFQ Page</a>
TE-703-B-12-B	TE-703-B-12-B	<a href="#">Open Product RFQ Page</a>
TE-703-B-12-B-1	TE-703-B-12-B-1 t ° probe	<a href="#">Open Product RFQ Page</a>
TE703D12B-1/4NPT	TE703D12B-1/4NPT (TE-703-D-12-B-2) TEMPERATURE SENSOR TE-703-D-12B 1/4 "NPT	<a href="#">Open Product RFQ Page</a>
TE-704-A-12	TE-704-A-12	<a href="#">Open Product RFQ Page</a>
TE-704-A-7	TE-704-A-7	<a href="#">Open Product RFQ Page</a>
TE-706-B-12	TE-706-B-12	<a href="#">Open Product RFQ Page</a>

#### Axiparts Offices

Germany Head Office: Lise-Meitner-Straße 13, 89081 Ulm, Germany

USA Office: 16225 Park Ten Pl #500, Houston, TX 77084, United States

Dubai Office: HDS Business Centre Tower, Cluster M, 33rd Floor, Jumeirah Lake Towers, Dubai, United Arab Emirates